




Wired Gaming Mouse ABMO2

Product Description



EN

Important Safeguards

⚠ DANGER Risk of suffocation! Keep any packaging materials away from children and pets – these materials are a potential source of danger, e.g. suffocation.

⚠ CAUTION Avoid looking directly into the beam.


- Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.
- Protect the product from extreme temperatures, hot surfaces, open flames, direct sunlight, water, high humidity, moisture, strong jolts, flammable gases, vapors and solvents.
- Do not bend or kink the cable.
- This product is intended to be used in dry areas only.

Explanation of Symbols

	Direct current (DC)
	USB plug

Connection

Connect the USB plug (A) to a compatible USB port of the computer (Fig. 1).



NOTICE The product does not work on glass surfaces. Use a mouse pad.

Operation

Left button (B)	Default button used to click, select, drag to highlight a word and/or object.
Scroll wheel (C)	Used to scroll up and down on any page without using the vertical scroll bar on the right hand side of a document or web page.
Right button (D)	Typically used to provide additional information and/or properties of selected item.
Back buttons (E)	Used to view the previous page of a web page.
Forward buttons (F)	Used to view the next page of a web page.
Thumb button (G)	Press once for a double-click.
DPI decrease button (H)	Used to decrease the cursor speed.
DPI increase button (I)	Used to increase the cursor speed.

Cleaning and Storage

NOTICE

- During cleaning do not immerse the product in water or other liquids. Never hold the product under running water.
- Unplug before cleaning.

- To clean the product, wipe with a soft, slightly damp cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.
- Store the product in its original packaging in a dry area. Keep away from children and pets.


Specifications

Model number	ABMO2
Rated voltage	5 V \equiv 310 mA
OS compatibility	Windows®XP/ 7/ 8/ 10/ Vista, macOS®
USB cable length	1.6 m (braided cable)
Sensitivity	240-7200 DPI
Acceleration	20 G
Refresh rate	125 Hz


Function LED	5 red LED
Net weight	approx. 141.8 g
Dimensions	approx. 7.2 x 4.1 x 13.5 cm

How to Install


1) Plug the USB Gaming Mouse in your Computer or Laptop :




2) Open Application Setup on your Computer/Laptop :




3) Application Will Pop-up up Setup Wizard Just click on the Next Button :




4) Select Destination Location Just Click Next:




5) Just Click the Install Button :




6) After the Click on the Install button The Application will be open automatically :




7) Basic Setup :




8) Macro Setup :



9) Performance Setting Adjustment of Mouse Setup :



10) Backlight Adjustment Setting :



Amazon Brand - India E-waste Program
Recycle your old Amazon brand products and help protect the environment.

Consequences of Improper E-Waste Handling & Recycling:

E-waste when disposed or recycled improperly, can cause severe environmental pollution and adversely affect the human body as they contain excess of toxic chemicals like mercury, polybrominated flame retardants, barium, lithium and PVC. The common process of burning of e-waste in informal e-waste recycling and disposal facilities releases toxic gases into the atmosphere, causing severe air pollution. Besides that, poor recycling and improper disposal of e-waste leads to a lot of pollutants such as heavy metals like cadmium, lead and persistent organic pollutants to be released into the atmosphere, which further pollutes the eco-system and causes health hazards.

Alternately the practice of dumping of e-waste into landfills as followed by the informal e-waste recycling and disposal facilities eventually makes the hazardous and toxic components of e-waste seep into the eco-system including the regional water tables, causing soil pollution and contaminating the water table.

Such contamination will affect nearby communities in an adverse manner for much longer time. Accidental breakage and damage of electronics and e-waste can pose a threat to the environment. As long as the toxic components in electronics are enclosed within the original manufacturer's designed outer-shell of the gadget, they don't pose much of a danger as they have been engineered to contain any such effects. However, accidental breakage or damage of such electronics or e-waste can lead to toxic elements leaking and contaminating their immediate environment. Damage to the environment due to accidental breakage of e-waste is a major concern in informal e-waste disposal and recycling facilities, so consumers need to ensure that their e-waste is being disposed only through authorized recycling points.

Amazon Brand Recycling Program (India):
Retek Envirotech Private Limited ("Retek"), a recycling company, has been authorized to provide e-waste disposal service to all customers who have purchased Amazon brand products. Reteck has a PAN-India collection mechanism for collecting e-waste from customers and for further disposal of such e-waste as per the E-Waste (Management & Handling) Rules, 2016 effective October 1, 2016 and amendments therein.

Retek will provide e-waste drop off points and ensure environmentally sound management of electronics that have reached their end-of-life phase. Reteck has all the necessary authorizations from the appropriate governmental agencies for their processing facilities. Reteck ensures proper recycling and disposal of e-waste, and does not incinerate, send e-waste to landfill or export hazardous e-waste to other countries. This helps us protect the environment from any hazardous consequences, which would be otherwise caused by the inappropriate waste management of e-waste.

To know more about Reteck collection points and how to recycle your Amazon brand product - (i) Log on to <https://www.reteck.co/recycling> or (ii) Call up Toll Free Number: 1800-212-2426 or (iii) Write to - info@reteck.in

Instructions of handling the product during and after its use and Do's and Don'ts with respect to handling the product:

Do's:

- Always look for information in the product's user's guide for end-of-life equipment handling.
- Ensure that only authorized recyclers handle your electronic products.
- Always call local authorized e-waste collection centers to dispose products that have reached end-of life phase.
- When your used electronic products, batteries or accessories reach the end of their life, always dispose them at your nearest authorized e-waste collection center.
- Wherever possible or as instructed, separate the packaging material according to responsible waste disposal options and sorting for recycling.
- Always ensure any glass surface is protected against breakage.
- Kindly ensure that the product is properly packaged as per instructions before handing it over to the authorized Recycler.

Don'ts:

- Do not dismantle your electronic products on your own.
- Do not throw electronics having "Do not Dispose" symbol on the product package in your regular garbage bins along with municipal waste since it will ultimately reach a landfill.
- Do not give e-waste to informal and unorganized sectors like local scrap dealers.

Be a Responsible User. Recycle your E-Waste for a Greener Planet.

Warranty and Customer Service Information

For Customer service related queries and claiming warranty:

- Go to 'Your orders' section on Amazon website
- Select the product
- Click on 'Get product support' and
- Schedule an appointment